Wireless Nurse Call Model ENS48

😌 Super Nurse Call

ſ	a root a court	• ***** * <u>*</u>	
HC	ROOM NUMBER	ROOM NUMBER	ROOM NUMBER
č	ROOM NUMBER	ROOM NUMBER	ROOM NUMBER
č	ROOM NUMBER	HOOM NUMBER	ROOM NUMBER
č	ROOM NUMBER	ROOM NUMBER	ROOM NUMBER
č	ROOM NUMBER	ROOM NUMBER	NOOM MUMBER
F	ROOM NUMBER	ROOM NUMBER	ROOM MUMBER
F	HOCM NUMBER	ROOM NUMBER	HOOM NUMBER
č	ROOM NUMBER]	ROOM NUMBER)	ROOM MUMBER
F	ROOM NUMBER	ROOM NUMBER)	ROOM MUMBER
F	ROOM NUMBER	HOOM NUMBER	ROOM NUMBER
ē	ROOM NUMBER]	HOOM NUMBER]	HOOM NUMBER
E	ROOM NUMBER	HOOM NUMBER) (POOM MUMBER
Č	ROOM NUMBER) (ROOM NUMBER]	ROOM NUMBER
C	ROOM NUMBER)	ROOM NUMBER)	NOOM NUMBER
C	ROOM NUMBER	ROOM NUMBER] [HOOM MARBER
č	HOOM NUMBER]	ROOM NUMBER	ROOM NUMBER

FEATURES:

 Simple, Highly Visual 48 Room Nurse Call Annunciator, UL2560 Compliant

 Built-In Inovonics Receiver,
 Works with -60 and other Transmitters
 Register up to Five Devices per Room

 Removable Clear Cover and
 Room Identification Form
 External Adjustable Alarm Chime
 One Touch Alarm Acknowledge/Silence
 Serial Output for Pagers and Computer

SPECIFICATIONS

MOUNTING	Surface Mount - Enclosure screws to wall with two four screws. Lid removes with four screws to acces control for programming.	
SIZE	11 1/2" x 17 1/2" x 2 1/2"	
COLOR	Black Plastic with Clear Cover and Room identification Form	
POWER	Includes Plug-In AC Transformer and Back-Up Battery	
INPUTS	Inovonics Wireless -60 and other Transmitters	
OTHER	Serial Connections for Pager and Computer	





Trusted Technology for Super Caregivers

Accessories from Flair:

Panic Switches
 Pull Cords
 Motion Sensors
 Magnetic Contacts
 Water Sensors

OPERATION:

Information at a Glance

Flair Wireless ENS48 Nurse Call Annunciator has a built-in Inovonics receiver and works with -60 and other transmitters. Registration of transmitters is easily performed using the LCD screen and push buttons on face plate or computer software. Each room has a red flashing LED for alarm. LEDs at top of annunciator provide status of power, transmitter batteries and transmitter communication. Adjustable alarm chime and silence button are located on top. ENS48 has serial interface for sending alarm messages to pagers and computer. Event log may be accessed on LCD or computer.